


Instructions



1. Insert Allen key into lock.
2. Loosen and remove lock.
3. Unsnap the bottom to release the frame.
4. Unsnap all 4 sides and place artwork under front cover.